

Клапаны с колесным приводом JV-205-00

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: ahq@nt-rt.ru || сайт: <https://asha.nt-rt.ru>

Wheel Operated (JV-205-00)



•

Nitrous oxide valve (wheel operated) (JV-205-00)

Nitrous oxide valve (wheel operated) (JV-205-00) is key-operated valve features a durable High Tensile Brass body and a Nylon (PA6) soft seat for precise Nitrous oxide flow control. Ideal for industrial and commercial applications, it ensures reliable and efficient performance.

Model

- **Gas Service:** Nitrous oxide
- **Wheel Operated:** Wheel Operated

Features

- **Valve Body:** HT brass / Steel
- **Spindle:** Speed Steel
- **Gland Packing Washer:** Free Cutting Brass
- **Gland Packing:** PTFE
- **Gland Nut:** Free Cutting Brass
- **Handwheel:** Al. Alloy/ABS
- **Hex Nut:** MS (Zn Plated)

Valves Nitrous Oxide (Key Operated) (JV-205-00)

Sr.No.	Gas Service	Key Operated	Inlet Thread Size * (As Per Customer Requirement)								Outlet Thread Size	Pitch Measured Along The Cone	Outlet No.of IS:3224	Working Pressure (Kgf/cm2)	Hydraulic Test Pressure (Kgf/cm2)
1	N ₂ O (Nitrous Oxide)	Key Operated	1/2"	17E * per C.R)	3/4"	25E * per C.R)	1"	1-1/4"	1-1/2" * per C.R)	M18X1.5 * per C.R)	Ext W17.46 X 1.27 (RH)	1.27	12	200	300

Valve (Material of Construction) JV-205-00

Sr.No.	Description	Material	Specification
1	Valve Body	HT Brass	IS:3224
2	Spindle	Speed Steel	-----
3	Gland Packing Washer	Free Cutting Brass	IS:319
4	Gland Packing	PTFE	-----
5	Gland Nut	Free Cutting Brass	IS:319
6	Handwheel	Al.Alloy / ABS	-----
7	Hex Nut	MS (Zn.Plated)	-----

Technical Details (JV-205-00)

➡	K/O Minimum Valve closing Torque	10-12 Nm
➡	W/O Minimum Valve closing Torque	5-7 Nm
➡	K/O Valve Gland nut installation	70-80 Nm
➡	W/O Valve Gland nut installation	70-80 NM
➡	Operating temperature range	-20°C to 65°C
➡	Storage temperature range	-40°C to 65°C
➡	Minimum life cycle	6000 Cycles
➡	Valve working pressure	See as per table
➡	Valve hydrostatic pressure	See as per table
NOTE:		
K/O (Key Operated)		
W/O (Wheel Operated)		

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: ahq@nt-rt.ru || сайт: <https://asha.nt-rt.ru>