

# Клапан пережима JV-207-00

## Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04  
Ангарск (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922)49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Ноябрьск (3496)41-32-12  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37  
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Саранск (8342)22-96-24  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Сыктывкар (8212)25-95-17  
Тамбов (4752)50-40-97  
Тверь (4822)63-31-35

Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Улан-Удэ (3012)59-97-51  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: [ahq@nt-rt.ru](mailto:ahq@nt-rt.ru) || сайт: <https://asha.nt-rt.ru>

# Squeeze Valve (JV-207-00)



## Carbon dioxide (CO2) Squeeze valve (JV-207-00)

Carbon dioxide (CO2) Squeeze valve (JV-207-00) is key-operated valve features a durable High Tensile Brass body and a Nylon (PA6) soft seat for precise Carbon dioxide flow control. Ideal for industrial and commercial applications, it ensures reliable and efficient performance.

## Model

- **Gas Service:** Carbon dioxide
- **Handle Operated:** Handle Operated

## Features

- **Squeeze Valve Body CO2:** HT Brass
- **"O" Ring (Spring Retainer Plug) :** Nitrile/Neoperene Rubber
- **Spring Retainer Plug:** Free Cutting Brass
- **Spring:** Spring Steel
- **Seat Holder:** Free Cutting Brass
- **Seat:** Nitrile/Neoperene Rubber
- **Stem:** Free Cutting Brass
- **Spilt Dowl/Rivet:** M.S/Aluminium

## CO<sub>2</sub> Squeeze Valve (JV-207-00)

| Sr.No. | Gas Service                      | Handle Operated | Inlet Thread Size * (As Per Customer Requirement) |                   |      |                   |    |        |                      |                       | Outlet Thread Size     | Pitch Measured Along The Cone | Outlet No.of IS:3224 | Working Pressure (Kgf/cm2) | Hydraulic Test Pressure (Kgf/cm2) |
|--------|----------------------------------|-----------------|---------------------------------------------------|-------------------|------|-------------------|----|--------|----------------------|-----------------------|------------------------|-------------------------------|----------------------|----------------------------|-----------------------------------|
| 1      | CO <sub>2</sub> (Carbon Dioxide) | Handle Operated | 1/2"                                              | 17E *<br>per C.R) | 3/4" | 25E *<br>per C.R) | 1" | 1-1/4" | 1-1/2" *<br>per C.R) | M18X1.5 *<br>per C.R) | Ext W21.8 X 1.814 (RH) | 1.814                         | 7                    | 160                        | 240                               |

### Valves (Material of Construction) JV-207-00

| Sr.No. | Description                     | Material                 | Specification         |
|--------|---------------------------------|--------------------------|-----------------------|
| 1      | Squeeze Valve Body CO2          | HT Brass                 | IS:3224/IS:6912       |
| 2      | "O" Ring (Spring Retainer Plug) | Nitrile/Neoperene Rubber | -----                 |
| 3      | Spring Retainer Plug            | Free Cutting Brass       | IS:319                |
| 4      | Spring                          | Spring Steel             | -----                 |
| 5      | Seat Holder                     | Free Cutting Brass       | IS:319                |
| 6      | Seat                            | Nitrile/Neoperene Rubber | -----                 |
| 7      | Stem                            | Free Cutting Brass       | IS:319                |
| 8      | Spilt Dowl/Rivet                | M.S/Aluminium            | -----                 |
| 9      | "O ring (Stem)                  | Nitrile/Neoperene Rubber | -----                 |
| 10     | Locking Pin                     | M.S                      | Crome Plated          |
| 11     | Handle Upper                    | M.S                      | Powder Coated (Black) |
| 12     | Handle Lower                    | M.S                      | Powder Coated (Black) |
| 13     | Tie for Locking Pin             | PVC/Rubber               | -----                 |
| 14     | Brusting Disc                   | Copper                   | -----                 |
| 15     | Copper Washer                   | Copper                   | -----                 |
| 16     | Safety Plug                     | Free Cutting Brass       | IS:319                |
| 17     | Spilt Pin                       | S.S                      | -----                 |

#### Technical Details (JV-207-00)

|                                |                 |
|--------------------------------|-----------------|
| ➡ Valve Gland nut installation | 60 Nm           |
| ➡ Valve retainer plug          | 12 Nm           |
| ➡ Safety disc burst pressure   | 200-220 kgf/cm2 |
| ➡ Operating temperature range  | -20°C to 65°C   |
| ➡ Storage temperature range    | -40°C to 65°C   |
| ➡ Minimum life cycle           | 6000 Cycles     |
| ➡ Valve working pressure       | 160 kgf/cm2     |
| ➡ Valve hydrostatic pressure   | 240 kgf/cm2     |

## По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04  
Ангарск (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922)49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Ноябрьск (3496)41-32-12  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37  
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Саранск (8342)22-96-24  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Сыктывкар (8212)25-95-17  
Тамбов (4752)50-40-97  
Тверь (4822)63-31-35

Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Улан-Удэ (3012)59-97-51  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93

**Россия** +7(495)268-04-70

**Казахстан** +(727)345-47-04

**Беларусь** +(375)257-127-884

**Узбекистан** +998(71)205-18-59

**Киргизия** +996(312)96-26-47

эл.почта: [ahq@nt-rt.ru](mailto:ahq@nt-rt.ru) || сайт: <https://asha.nt-rt.ru>