

Одноступенчатые регуляторы с одним счетчиком серии Есо (ISI), выходное давление (0-10 бар) Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: ahq@nt-rt.ru || сайт: <https://asha.nt-rt.ru>

Single Stage Single Meter Regulator (Eco Series) (ISI) Outlet Pressure (0-10 Bar)



Single Stage Single Meter Oxygen Regulator (Eco Series)

Single Stage Single Meter Oxygen Regulator (Eco series) is designed for installation on tanks or on cylinders with an inlet pressure of 0-400 Bar, and outlet/working pressure of 0-10 Bar. The valve comes with overpressure protection with the Safety pressure of 12 Bar.

- **Item:** Single Stage Single Meter Oxygen Regulator (Eco Series)
- **Inlet for:** Oxygen

Features

- **Inlet Pressure:** 0-400 Bar
- **Outlet/Working Pressure:** 0-10 Bar
- **Safety Pressure:** 12 Bar
- **Inlet Connection (Oxygen):** G5/8"A - 14 TPI (RH)
- **Outlet Connection:** 3/8" - 19 BSP (RH)



Single Stage Single Meter Nitrogen Regulator (Eco Series)

- **Item:** Single Stage Single Meter Nitrogen Regulator (Eco Series)
- **Inlet for:** Nitrogen

Features

- **Inlet Pressure:** 0-400 Bar

- **Outlet/Working Pressure:** 0-10 Bar
- **Safety Pressure:** 12 Bar
- **Inlet Connection (Nitrogen):** G 3/4" -14 TPI- RH
- **Outlet Connection:** 3/8" - 19 BSP (RH)



Single Stage Single Meter Nitrous Oxide Regulator (Eco series)

- **Item:** Single Stage Single Meter Nitrous Oxide Regulator (Eco series)
- **Inlet for:** Nitrous Oxide

Features

- **Inlet Pressure:** 0-400 Bar
- **Outlet/Working Pressure:** 0-10 Bar
- **Safety Pressure:** 12 Bar
- **Inlet Connection (Nitrous Oxide):** W17.42 x 1.27 (RH)
- **Outlet Connection:** 3/8" - 19 BSP (RH)



Single Stage Single Meter Carbon Dioxide Regulator (Eco Series)

- **Item:** Single Stage Single Meter Carbon Dioxide Regulator (Eco Series)
- **Inlet for:** Carbon Dioxide

Features

- **Inlet Pressure:** 0-400 Bar
- **Outlet/Working Pressure:** 0-10 Bar
- **Safety Pressure:** 12 Bar
- **Inlet Connection (Carbon Dioxide):** W21.8 -1.814 (RH)

- **Outlet Connection:** $\frac{3}{8}$ " - 19 BSP (RH)



Single Stage Single Meter Argon Regulator (Eco series)

- **Item:** Single Stage Single Meter Argon Regulator (Eco series)
- **Inlet for:** Argon

Features

- **Inlet Pressure:** 0-400 Bar
- **Outlet/Working Pressure:** 0-10 Bar
- **Safety Pressure:** 12 Bar
- **Inlet Connection (Argon):** G $\frac{3}{4}$ " -14 TPI- RH
- **Outlet Connection:** $\frac{3}{8}$ " - 19 BSP (RH)



Single Stage Single Meter Hydrogen Regulator (Eco series)

- **Item:** Single Stage Single Meter Hydrogen Regulator (Eco series)
- **Inlet for:** Hydrogen

Features

- **Inlet Pressure:** 0-400 Bar
- **Outlet/Working Pressure:** 0-10 Bar
- **Safety Pressure:** 12 Bar
- **Inlet Connection (Hydrogen):** G $\frac{5}{8}$ "A -14 TPI (LH)
- **Outlet Connection:** $\frac{3}{8}$ " - 19 BSP (LH)



Single Stage Single Meter Helium Regulator (Eco series)

- **Item:** Single Stage Single Meter Helium Regulator (Eco series)
- **Inlet for:** Helium

Features

- **Inlet Pressure:** 0-400 Bar
- **Outlet/Working Pressure:** 0-10 Bar
- **Safety Pressure:** 12 Bar
- **Inlet Connection (Helium):** G 3/4" -14 TPI- RH
- **Outlet Connection:** $\frac{3}{8}$ " - 19 BSP (RH)



Single Stage Single Meter Air Regulator (Eco Series)

- **Item:** Single Stage Single Meter Air Regulator (Eco Series)
- **Inlet for:** Air

Features

- **Inlet Pressure:** 0-400 Bar
- **Outlet/Working Pressure:** 0-10 Bar
- **Safety Pressure:** 12 Bar
- **Inlet Connection (Air):** G 7/8" -14 TPI- RH
- **Outlet Connection:** $\frac{3}{8}$ " - 19 BSP (RH)



Single Stage Single Meter Da Regulator (Eco Series) Outlet Pressure (0-5 Bar)

- **Item:** Single Stage Single Meter Da Regulator (Eco Series) Outlet Pressure (0-5 Bar)
- **Inlet for:** Acetylene

Features

- **Inlet Pressure:** 0-40 Bar
- **Outlet/Working Pressure:** 0-5 Bar
- **Inlet Connection (Acetylene):** G 5/8"A -14 TPI (LH)
- **Outlet Connection:** $\frac{3}{8}$ " - 19 BSP (LH)

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: ahq@nt-rt.ru || сайт: <https://asha.nt-rt.ru>